

iLuv®

Designed by iLuv in New York

Mo' Beats HD

NFC-Enabled Rechargeable Bluetooth Speaker with Viewing Cradle

Model No. MOBEATSHDLK

Quick Start Guide

CONTENTS

Model No. MOBEATSHDLK

SAFETY INFORMATION	3, 4
WHAT'S INCLUDED	5, 6
CONTROLS	7, 8, 9, 10
CHARGING	11, 12
PAIRING	13 - 24
USING BUILT-IN CRADLE	25, 26
SPECIFICATIONS	27
WARRANTY	28

WHAT'S INCLUDED

- Mo'Beats HD Main Unit
- AC Adapter
- USB Charging Cable

CONTROLS

- Power/Bluetooth LED: White
- Battery LED: Red
- SRS Sound LED: Red
- NFC Antenna

CONTROLS

- Play/Pause/Pair
- Previous Track
- Next Track
- Volume Down
- Volume Up
- SRS on/off (Enhances Sound Stage)

CHARGING

Fully charge speaker before use

- Connect micro-USB cable to the micro-USB port on the Mo'Beats HD.
- Connect the other end of USB cable to your computer or USB adapter to charge.
- Charging indicator will turn red while charging during power off mode. Indicator will turn off when fully-charged, and flash slowly when the battery is low.

PAIRING (VIA NFC)

Make sure that you have back NFC

- Switch ON (located on back of device).
- Enable NFC and Bluetooth on your phone (NFC settings may be found under your device's "More/Additional Settings").

Compatibility: Most smartphones with NFC running Android 4.1 "Jellybean" and later.

PAIRING (VIA NFC)

- Lightly swipe your phone down the NFC logo on top of device, while making minimal contact. Mo'Beats HD should say "Pairing Successful!"

If Mo'Beats HD is already paired to a smartphone, press and hold the pair button until the device disconnects before pairing it with another smartphone.

PAIRING (MANUALLY)

iPad settings shown; your device settings may vary

- Go to "Settings"/"General"/"Bluetooth"
- Turn Bluetooth ON / Scan for nearby devices

PAIRING (MANUALLY)

- Switch ON (located on back of device)
- Press and hold pair button to initiate discovery mode
- Pairing indicator will flash blink white when in discovery mode

PAIRING (MANUALLY)

- Wait until 'iLuv Mo'Beats HD' pairing appears on your mobile device and enable it to connect
- If your device prompts you to enter a PIN code, enter '0000'

PAIRING (MANUALLY)

- When successfully paired, the pairing indicator on Mo'Beats HD will flash steadily

Pairing Successful!

USING BUILT-IN CRADLE

- Stand out the retractable stand and set Mo'Beats HD on a flat surface
- Fit your open device securely in the rubberized groove on a flat surface

SPECIFICATIONS

1 Weight	0.7kg / 1lb 8.69oz
2 Dimensions (W x H x D)	280mm x 80mm x 93mm 11in x 3.2in x 3.7in
3 BT Version	BT2.1+EDR, NFC BT pairing
4 Connectors	AUX-IN
5 Input Power	USB, 5V 500mA charging
6 Output Power	3W x 2 @1%THD

SAFETY INFORMATION (USA)

INTERNAL RECHARGEABLE LITHIUM-ION BATTERY

THIS DEVICE USES AN INTERNAL RECHARGEABLE LITHIUM-ION BATTERY THAT SHOULD LAST THE LIFE OF THE DEVICE. IF YOU SUSPECT YOUR BATTERY MAY BE DEAD, TRY CHARGING IT SEVERAL TIMES. IF THE BATTERY DOES NOT RECHARGE, PLEASE CONTACT US FOR REPAIR INFORMATION.

WARNING/DEPOSAL OF UNIT

Never dispose of used batteries/electronics with ordinary waste, since they contain toxic substances. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are special regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices.

CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if mis-treated.

Never disassemble the unit or attempt to remove battery as this could cause leakage of alkaline solution or other electrolytic substance. Always confirm that the temperature is 32°C (90°F) or below before you charge the battery. Leakage or deterioration of the battery may occur if the battery is not recharged.

Never expose the battery to any liquid.

Never immerse the battery in water, such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.

Always keep the battery out of the reach of infants and small children.

SAFETY INFORMATION (EUROPE)

IMPORTANT SAFETY INSTRUCTIONS

- Read all warnings.
- Follow all safety instructions.
- Do not use this apparatus near water.
- Do not use this apparatus in the vicinity of flammable vapors, fumes, or other devices including amplifiers that produce heat.
- Do not use any accessories specified by the manufacturer.
- Refer all servicing to a qualified service personnel. Servicing is required when the device has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, the device has been exposed to rain or moisture, excessive heat or cold has been experienced, or the power supply cord or plug has been frayed or broken.
- Do not touch any surfaces of charge on the device that are not expressly approved by iLuv Creative Technology™ may void the user's authority to operate the equipment.

NOTICE

Any changes or modifications made to this device that are not expressly approved by iLuv Creative Technology™ may void the user's authority to operate the equipment.

This product conforms to all applicable EU Directive requirements.

DISPOSAL OF YOUR OLD PRODUCT

When this product is no longer needed, it should be attached to a product if means that the product is covered by a warranty. Please inform yourself about the local separate collection system for electrical and electronic products. Please do not discard this product as your local law, and do not dispose of your old product with your normal household waste. Connect disposal of your old product helps to prevent potential negative consequences for the environment and human health. Always bring your product to a professional to remove the built-in battery.

FR | CE QUI EST INCLUS

- Unité principale
- Adaptateur secteur
- Câble de charge USB

FR | COMMANDES

- LED de charge/Bluetooth Blanc
- LED de batterie Rouge
- LED du son SRS Rouge
- Antenne NFC

FR | CONTRÔLES

- Reproduction/Pause/Aléatoire
- Précédent
- Prochain
- Volume Diminuer
- Volume Augmenter
- SRS on/off (Améliore l'étape sonore)

FR | CHARGEMENT

Chargez complètement le haut-parleur avant utilisation.

- Connectez le câble micro-USB à l'unité sur le port micro-USB. Débranchez le câble micro-USB de votre ordinateur ou adaptateur USB.
- Le voyant de charge va clignoter rouge pendant le chargement et s'éteindra lorsque le haut-parleur sera complètement chargé.
- Le voyant de charge va clignoter rouge pendant le chargement et s'éteindra lorsque le haut-parleur sera complètement chargé.

FR | APPARIAGE (VIA NFC)

Assurez-vous que votre appareil dispose de NFC.

- Activez le NFC et Bluetooth sur votre téléphone. Les paramètres NFC peuvent varier selon les appareils. Consultez les paramètres NFC de votre téléphone.
- Activez le NFC et Bluetooth sur votre appareil. Les paramètres NFC peuvent varier selon les appareils. Consultez les paramètres NFC de votre appareil.

FR | APPARIAGE (VIA NFC)

Légèrement glissez votre téléphone sur le logo NFC en haut de l'appareil, tout en établissant un contact minimal. Mo'Beats HD devrait dire "Appariement réussi!"

FR | APPARIAGE (MANUELLEMENT)

Allez dans "Paramètres"/"Général"/"Bluetooth"

- Activez Bluetooth.
- Appuyez sur "Rechercher de nouveaux appareils"

FR | APPARIAGE (MANUELLEMENT)

Attendez que l'appareil Mo'Beats HD apparaisse sur votre appareil mobile et activez-le pour qu'il se connecte.

FR | APPARIAGE (MANUELLEMENT)

Une fois que l'appareil Mo'Beats HD est apparié, le voyant de charge va clignoter blanc.

FR | UTILISATION DU SÉJOUR EN CRADLE

- Sortez le support rétractable et placez votre appareil sur une surface plane
- Insérez votre appareil dans la rainure caoutchoutée sur une surface plane

FR | GARANTIE

Garantie limitée de 2 ans

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>