

## Package contents

- 360 Chat Headset
- *Quick Setup Guide*


## Using your headset

- 1 Turn down the volume on the 360 Chat Headset in-line control by rotating the volume control all the way down. Insert the 2.5 mm headset connector into the controller expansion port at the bottom of your game controller.



- 2 Put on the 360 Chat Headset and adjust the microphone to your preferred position.

**Note:** Correct placement of the headset and microphone is critical to using your headset successfully.



Make sure that the headset goes over the top of your head, not around the back of your head. Position the microphone about one inch (2.54 cm) from your mouth and off to one side.

- 3 Start your game or chat and turn the volume up to a comfortable level.

**Warning:** Extended exposure to high volumes when using a headset may result in temporary or permanent hearing loss.



### To mute the 360 Chat Headset:

- Slide the mute switch on the in line control.



## FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## ICES-003

This Class B digital apparatus complies with Canadian ICES-003; Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## 90-day limited warranty

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

## Contact Insignia:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)  
[www.insigniaproducts.com](http://www.insigniaproducts.com)

Microsoft and Xbox 360 are registered trademarks of the Microsoft group of companies.

1-877-467-4289

[www.insigniaproducts.com](http://www.insigniaproducts.com)

Registered in some countries.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2014 Best Buy. All rights reserved.

Made in China

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>