


CX 400



Important safety instructions

To avoid damage to your hearing:

- Set a low volume setting before inserting the earphones!
- Do not use the earphones for long periods of time with a high volume setting!

To avoid damage to your auditory canals and eardrum:


- Place suitable pads on the earphones (S, M or L). Never insert the earphones without pads!
- Always insert and remove the earphones from the auditory canal **slowly** and **carefully**! Do not insert the earphones too far into the ear!
- Always keep the earphones dry.

To prevent accidents:

Do not use the earphones in environments in which particular attention must be paid (e.g. on roads or while carrying out manual work).

Note on sound quality

The sound quality of the earphones, incl. bass performance, depends largely on correct positioning. To achieve the best possible sound results, the accompanying ear pads or earphone covers should therefore be used.



Sennheiser electronic GmbH & Co. KG
30900 Wedemark, Germany
Phone +49 (5130) 600 0
Fax +49 (5130) 600 300
www.sennheiser.com

Printed in Germany

Publ. 06/07

525131/A01

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>