Form 2421w (Rev. 853) Printed in U.S.A.

DO NOT REMOVE

LIST of PARTS



SINGER"

MACHINE No. 136w105

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling, and when in continuous use, "TYPE B" or "TYPE D" OIL, sold by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL", as instructed in Form 2236w.

"TYPE D" OIL should be used when an oil is desired which will produce a minimum of stain on fabrics, even after a long period of storage.

The small felt pad on the side of the bobbin case should be kept wet with oil to lubricate the hook race.

Occasionally check the grease in gear cases on the underside of the bed of the machine and fill gear cases, when necessary, with GEAR LUBRICANT, sold by Singer Sewing Machine Company.

INDEX

1	Page
ccessories	1
obbin Winder	17
eed Gears	19
nee Lifter	18
nife Honing Device	20
achine No.136w105	5
umerical List of Parts	23
roat Plates	21
ood Base	22

Copyright, U. S. A., 1938, 1939, 1940, 1941 and 1954 by The Singer Manufacturing Company All Rights Reserved for All Countries In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case), must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed.

AL-Heat Treated for Toughness.

ALX—Heat Treated for Toughness and Black Oxide.

B-Polished, Nickel Plated and Buffed.

C-Hardened only.

D-Polished only.

E-Soft, Not polished.

F-Hardened and Polished.

J-Nickel Plated only.

R-Merlized.

X-Black Oxide, for Iron and Steel.

XC-Hardened and Black Oxide, for Iron and Steel.

Y-Black Nickel Plated only.

Z-Chromium Plated.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers.

1501 to 1800, 201501 to 201800 and 351501 to 351800 are Nut Numbers.

1801 to 2000, 201801 to 202000 and 351801 to 352000 are Roller Numbers.


2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE



MACHINE No. 136w105

VERTICAL HOOK. POST BED.

CONTINUOUS WHEEL FEED.

BALL BEARING ROLLER PRESSER.

Horizontal Undertrimmer attached to Hook Post.

For Simultaneously stitching the edges and undertrimming the linings of Shoes, Sandals, Slippers, etc.

No.	Plate	Name
* 249069		Arm with 202135
249001		" Base
204235	17330	" Position Pin (2)
200004E	17330	" " Screw (3)
202005	17330	" " Washer (3)
203091	17325	" Cap
200278X	17325	" " Screw
202248	17325	" " Washer
203089	17325	" " Spool Holder Base
203090	17325	" " 203089 with
		200079X and 204296

						,
No.	Plate	Name		No.	Plate	Name
200585X		Arm Cap Spool Holder Base Screw	Ì	203216	17313	Bobbin Case Washer (cloth)
204296	17325	" " " Wire		238313	17313	Bobbin Case complete, Nos. 238304 and
200079X		" " " Hinge Screw	ĺ			238312
203092	17325	Arm Cap and Spool Holder complete,	!	237793	17325	Driving Wheel (aluminum alloy casting)
		Nos. 203090, 203091 and two 200585X				for "V" belt (outside diam. of belt
204235	17330	Arm Position Pin (2)				groove 2.9 in.) with 350540C and
200004E	17330	" Screw (3)				350541C
202005	17330	" " Washer (3)		350419X	17325	Driving Wheel Adjusting Screw
237702	17325	" Shaft with 224392 and 350431E	1	350540C	17325	" Position Screw
237748	17325	" " Bushing (back) with 202260	İ	350541C	17325	" Set Screw
202260	17325	" " " Oil Packing	İ	241732	17328	Edge Guide
		(wick)	}	241733	17328	" " Bracket
200071E	17325	Arm Shaft Bushing (back) Screw (3)		200934X		" " Hinge Screw
207080	17325	" " (front) with 202244	1	200380C		Tringe belew
202244	17325	" " " Oil Packing	1	241764	17328	" " Set Screw
		(wick)			1,500	
200502X	17325	Arm Shaft Bushing (front) Oil Packing		241684	17328	Packing (fibre) Edge Guide Locking Pin
		Thumb Screw		249272	17328	
350532E	17325	Arm Shaft Bushing (front) Set Screw	4	201537E	17328	" " " Releasing Handle
201522E	17325	" " Lock			1.500	Lock Nut
		Nut	1 3	50488C	17328	Edge Guide Locking Pin Screw Bushing
224392	17325	Arm Shaft Oil Packing (wick)	•	49273	17328	" " Spring
350431E	17325	" " Stop Screw	l.	49274	17328	Edge Guide Locking Device complete,
202632	15745	" Side Plate	1	, =	1,320	Nos. 241684, 249272, 249273, 350488C
200462X	15745	" " Thumb Screw	į			and two 201537E
*249276		Bed	1 2	00173X	17328	Edge Guide Screw (2)
202258	17330	" Hinge Connection (2)	1	37777	15745	Face Plate with 201650X and 350432XC
200570E	17330	" " Screw (4)		02135	15745	" " Position Pin
233939	17313	Bobbin		00473X	15745	" " Thumb Screw
238304	17313	" Case Base with 202056, 203211 to	· 1	49088	17327	Feed Post with 200362C, 200383C and
		203213 and 203216	A Pr	-,		two 201052C
203211	17313	Bobbin Case Base Latch	1 2	49268	17327	Feed Post 249088 with 249007, 249013,
*202056		" " Pin		1,200	1,36,	249014, 249019, 249077, 249078,
203212	17313	" " Plunger				249092, 249266 and four 200137X
203213	17313	" " Spring	2	49005	17326	
238312	17313	" Cap with 200984C, 203214,	4. 4	49278	17326	Feed Post Cover (back)
		203215, 241674, 241675, two each	31	00159F	17326	(tront)
		200594C and 350405C		001371	17320	(back of front) Clamp
234079	17326	Bobbin Case Lever	2	00E03V	17226	Screw (2)
234065	17326			00583X	17326	Feed Post Cover (back or front) Screw
200076D	17326	" " Driving Block " " " Screw	- 4	.0007	17177	(6)
LOUGIOD	11320	(2)		49007	17327	Feed Post Cover (side)
201272C	17226			00137X		" " Screw
241674	17326 17313	Bobbin Case Lever Hinge Screw	· 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1		17327	" " Screw (2)
241675	•	Outing 1 cit		49065	17327	" Wheel (coarse knurl)
	17313	Retaillet	21	49267	17327	" 249065 with 249062 and three
350405C		" " " Screw	11			229D
203214	17313	" Tension Spring	7 E		17327	Feed Wheel Adjusting Stud (eccentric)
200984C	1/313	Regulating		1052C		" " Set Screw
200501-0	177.3	Screw			17327	" Ball Bearing
200594C		Bobbin Case Tension Spring Screw			17327	" " Bearing
203215	17313	" " Thread Guide		0585X		" " Screw
200594C	17313	" " Screw	24	9062	17327	" Bevel Gear
			4			

8

			ł		
No.	Plate	Name	No.	Plate	Name
249012	17327	Feed Wheel Bevel Gear Driving Pinion	238616	15739	Feed Wheel Driving Gear Key Stop Pin
		with two 201052C	249075	15739	" " " Separating
350395C	17327	Feed Wheel Bevel Gear Driving Pinion			Washer (2)
201052C	17327	Screw Stud Feed Wheel Bevel Gear Driving Pinion	249030	15739	Feed Wheel Driving Gear Shaft with 238616
249013	17327	Set Screw Feed Wheel Bevel Gear Driving Pinion	249032	15739	Feed Wheel Driving Gear Shaft Bracket with 202299, 238630 and two 200346C
		Shaft (lower)	202299	15739	Feed Wheel Driving Gear Shaft Bracket
249014	17327	Feed Wheel Bevel Gear Driving Pinion			Oil Packing (wick)
2002026	17227	Shaft (lower) Bushing	249033	15739	Feed Wheel Driving Gear Shaft Bracket
200383C	17327	Feed Wheel Bevel Gear Driving Pinion			Plate with two 210983
249077	17227	Shaft (lower) Bushing Set Screw	210983	15739	Feed Wheel Driving Gear Shaft Bracket
249077	17327	Feed Wheel Bevel Gear Driving Pinion			Plate Position Pin
2003030	17227	Shaft (lower) Collar with two 200393C	200158X	15739	Feed Wheel Driving Gear Shaft Bracket
200393C	17327	Feed Wheel Bevel Gear Driving Pinion			Plate Screw (2)
21.0010	17227	Shaft (lower) Collar Set Screw	201082E	15739	Feed Wheel Driving Gear Shaft Bracket
248810	17327	Feed Wheel Bevel Gear Driving Pinion			Screw (long)
21.0077		Shaft (upper)	225532	15739	Feed Wheel Driving Gear Shaft Bracket
249077	17327	Feed Wheel Bevel Gear Driving Pinion			Screw (long) Washer
2002026		Shaft (upper) Collar with two 200393C	201308E	15739	Feed Wheel Driving Gear Shaft Bracket
200393C	17327	Feed Wheel Bevel Gear Driving Pinion			Screw (short)
31 0070		Shaft (upper) Collar Set Screw	203637	15739	Feed Wheel Driving Gear Shaft Bracket
249078	17327	Feed Wheel Bevel Gear Driving Pinion			Screw (short) Washer
31.0073		Shaft Connection	238630	15739	Feed Wheel Driving Gear Shaft Bushing
249073	17327	Feed Wheel Bevel Gear Driving Pinion Thrust Washer	249031	15739	" " " " Collar with 200397X
229D	17327	Feed Wheel Bevel Gear Screw	200397X	15739	Feed Wheel Driving Gear Shaft Collar
249096	17327	" " " Spacing Washer			Set Screw
249079	17327	" " Bracket	249037	15740	Feed Wheel Driving Pinion (for 15
249266	17327	" " 249079 with 248810,			stitches)
		249012, 249061, 249073, 249077, 249096, 249097, 249267, 350395C,	249038	15740	Feed Wheel Driving Pinion (for 16 stitches)
		350514AL and three 200585X	249040	15740	Feed Wheel Driving Pinion (for 18
249019	17327	Feed Wheel Bracket Friction Plug			stitches)
201052C	17327	" " " Set	231433	15740	Feed Wheel Driving Pinion Key
		Screw	249044	15740	" " Shaft
200362C	17327	Feed Wheel Bracket Set Screw	249045	15740	" " " Bushing (back)
350514AL	17327	" Cap Screw	200362C	15739	11 11 11 11 11
249023	15739	" " Driving Gear (for 15			Set Screw
		stitches)	249046	15740	Feed Wheel Driving Shaft Bushing
249024	15739	Feed Wheel Driving Gear (for 16			(front)
		stitches)	200346C	15739	Feed Wheel Driving Shaft Bushing
249026	15739	Feed Wheel Driving Gear (for 18		,	(front) Set Screw
		stitches)	249047	15740	Feed Wheel Driving Shaft Collar with
238613	15739	Feed Wheel Driving Gear Key			two 201052C
238614	15739	" " " Shifting	201052C	15740	Feed Wheel Driving Shaft Collar Set
		Collar with 201464C			Screw
201464C	15739	Feed Wheel Driving Gear Key Shifting Screw Stud	237724	15740	Feed Wheel Driving Shaft Gear with 200378C and 201220C
	15739	Feed Wheel Driving Gear Key Spring	201220C	15740	Feed Wheel Driving Shaft Gear Position
	13137		2002700	15760	
		0010W	2003186	15/40	Feed Wheel Driving Shaft Gear Set Screw
201202D	15739	Screw	200378C	15740	Screw Feed Wheel Driving Shaft

Name

No.

Plate

		10. 1004103	
No.	Plate	Name	
201666E	E 15740	Feed Wheel Driving Shaft Nut	
203411	15740	" " " Washer	
*203482		Hook (sewing)	
233853	17313	" 203482 with 201253F, 201376C and	
220215	12212	241604	
238315	17313	Hook and Bobbin Case complete, Nos.	
249049	17224	233853 and 238313	
234024	17326 17326	Hook Bevel Gear Socket, 14 teeth	
200555X		rriction washer	
241551	15740	Screw	
	13/10	" Pinion, 28 teeth, with two 200378C	!
201318E	15740	Hook Bevel Pinion Guard Oil Stop Screw	
201082E		" " " Screw	
*249050		" " Section (back)	
*249051		" " " (front)	
249052	15740	Hook Bevel Pinion Guard complete, Nos.	
		201082E, 201318E, 249050 and 249051	
200378C	15740	Hook Bevel Pinion Set Screw	
237728	15740	" Driving Shaft	
235857	15740	" " Bevel Gear with	
		200374C and 200396C	i
237729	15739	Hook Driving Shaft Bevel Gear Housing	
		with 200346C and three 200362C	
237730	15739	Hook Driving Shaft Bevel Gear Housing	
237731	1	Cap (bottom)	ĺ
237731	15739	Hook Driving Shaft Bevel Gear Housing	i
237732	15739	Cap (bottom) Gasket	i
	13137	Hook Driving Shaft Bevel Gear Housing Cap (side)	į
237733	15739	Hook Driving Shaft Bevel Gear Housing	
	,	Cap (side) Gasket	- 1
200053C	15739	Hook Driving Shaft Bevel Gear Housing	- 1
		Cap Screw (4)	- 1
301082E	15739	Hook Driving Shaft Bevel Gear Housing	- 1
		Screw (long)	- 1
225532	15739	Hook Driving Shaft Bevel Gear Housing	- 1
		Screw (long) Washer	1
201308E	15739	Hook Driving Shaft Bevel Gear Housing	- 1
		Screw (short)	1
203637	15739	Hook Driving Shaft Bevel Gear Housing	-
		Screw (short) Washer	3
500396C	15740	Hook Driving Shaft Bevel Gear Position	
200071		Screw	1 2
200374C	15740	Hook Driving Shaft Bevel Gear Set	
237734	1571.0	Screw	,
200362C	15740 15739	Hook Driving Shaft Bushing (back)	.0
2003020	13137	" " " " Set	
249053	15740	•	
200338C	15740	Hook Driving Shaft Bushing (front)	
		Screw " Set	
		6"	交锋

No.	Plate	Name
221743	15740	Hook Driving Shaft Collar with two
2002006	15760	200380C Hook Driving Shaft Collar Set Screw
200380C	15740 17313	" Gib
241604		" " Hinge Screw
201376C	17313	" " Screw
201253F	17313 17326	" Post
249280		
249072	17326	"
200959D		00.011 (2)
200017C	17326	56.6.1 (2)
203637	17326	washer (2)
221215	17326	Oriac
221222	17313	" Washer
249100	17330	Knee Lifter Lifting Lever
200242X		Thinge Betein
227561	17330	op. mg
241683	17330	Btop I mger
233390	17330	W asher
238508	17328	Knife
238530	15740	" Driving Eccentric with two 200386C
238510	15740	011 1 411
201058E		56.75 (-)
240019	15740	Offing 1 st
200386C		Ber Ber en
238512	15740	" " Fork Lever
249281	15740	230312
220512	15760	200243D, 201531X and 249282
238513	15740	Knife Driving Fork Lever Bracket with 200378C
202126	15740	Knife Driving Fork Lever Bracket Posi-
		tion Pin (2)
201058E	15740	Knife Driving Fork Lever Bracket Screw
		(2)
210910	15740	Knife Driving Fork Lever Hinge Stud
		with 202277
202277	15740	Knife Driving Fork Lever Hinge Stud
		Oil Packing (wick)
200378C	15740	Knife Driving Fork Lever Hinge Stud Set
		Screw
249282	15740	Knife Driving Fork Lever Slide Block
200243D	15740	н и и и и
		Hinge Screw
201531X	15740	Knife Driving Fork Lever Slide Block
		Hinge Screw Nut
241736	17328	Knife Driving Lever (lower) with
	-	200048C and 241752
241737	17326	Knife Driving Lever (lower) Guard
200158X	17326	H H H Screw
		(2)
200048C	17328	Knife Driving Lever (lower) Pinch

Screw

Knife Driving Lever (lower) Shaft

241738

17328

No.	Plate	Name
241739	17328	
		Nos. 104D, 24173 and 241736
241740	17328	Knife Driving Lever (upper) with
		200048C
241720	17328	Knife Driving Lever (upper) Locking
		Plunger Plunger
241721	17328	
		Plunger Spring
2017251	17328	Knife Driving Lever (upper) Locking
		Plunger Spring Thumb Nut with
		200389C
2003890	7 17328	Knife Driving Lever (upper) Locking
		Plunger Spring Thumb Nut Set Screw
200048C	17328	Knife Driving Lever (upper) Pinch
-1 1 .		Screw
241741	17328	Knife Driving Lever (upper) complete,
		Nos. 201725D, 241720, 241721 and
31.555		241740
241752	17328	Knife Driving Lever Fork
24173	17328	" " " Swivel
104D	1.500	" " " " Screw
249275	17326	" Guard
200110D		" " Screw (2)
241742	17328	" Lever
200168X		" Screw (2)
200169X 241743		" Screw (2)
241744	17328 17328	CATAIL
214833	17328	Spring
-2.000		" " " Adjusting Collar with
200380C	17328	
		Knife Shaft Spring Adjusting Collar Set Screw
241745	17328	Knife Switch-in Lever with 200061XC
200061XC		" " Pinch Screw
241746	17328	" Switch-out Lever
200284D	17328	
241747	17328	ninge Screw
249269	17329	Plunger Needle Bar with 200125F, 200175D and
	- *	249270
238251	17329	Needle Bar Connecting Link
264718	17329	" " Oil Guard
201183D	17329	Ul Guard
		Screw
202333	17329	Needle Bar Connecting Link Stud with
		202254
202254	17329	Needle Bar Connecting Link Stud Oil
	•	Packing (wick)
200374C	17329	Needle Bar Connecting Link Stud Set
		Screw
200383C	17329	Needle Bar Connecting Link Stud Set
		Screw
206891		Needle Bar Connecting Stud
		Service Control of the

No.	Plate	Name
202329	17329	Needle Bar Connecting Stud 206891 with
		200086C and 202330
202330	17329	Needle Bar Connecting Stud Oil Packing
		(wick)
200086	3 17329	,
202692	17329	
,-	,	200383C, 200428C and 202333
237737	17329	
	,	202399, 202400, 237762 and 238251
203172	17329	
2004280		
2003350		
202664	17329	
*237794	17325	
*237749	17325	U II II II II II
231117	11323	Body with 443C and 350107C
3501070	17325	Needle Bar Rock Frame Driving Ec-
3301070	, 11,02,	centric Body Position Screw
4430	17325	Needle Bar Rock Frame Driving Ec-
4450	, 11323	centric Body Set Screw
11030	17325	Needle Bar Rock Frame Driving Ec-
11050	, 11323	centric Regulating Screw
2171	17325	
2111	11363	centric Set Screw
7071	17325	Needle Bar Rock Frame Driving Ec-
7011	11723	centric Set Screw Washer
237750	17325	Needle Bar Rock Frame Driving Ec-
231130	11323	centric complete, Nos. 217D, 1103C,
		7071, 237749 and 237794
237739	17330	
231139	11330	Needle Bar Rock Frame Driving Fork Lever with 200029E
200025E	1-330	
ZUUUZ-E	1 330	Needle Bar Rock Frame Driving Fork
237740	1 = 330	Lever Pipel Seres
E31149	1 - 330	Needle Bar Rock Frame Driving Fork
210910	17110	Lever Slide Block (two pieces)
210910	17329	Needle Bar Rock Frame Hinge Stud with 202277
202277	17220	
202211	17329	Needle Bar Rock Frame Hinge Stud Oil
200347C	17330	Packing (wick)
200347C	17329	Needle Bar Rock Frame Hinge Stud Set
202///	17110	Screw
202666	17329	Needle Bar Rock Frame Position
300000=		Bracket
200098F	17329	Needle Bar Rock Frame Position
202//2		Bracket Screw
202667	17330	Needle Bar Rock Frame Rock Shaft
210978	17330	
303//2	17120	202667 with 200387C and 210920
202668	17330	Needle Bar Rock Frame Slide Block
2 10920	17330	
		202668 with 201141C

14

No.	Plate	Name
2011410	17330	Needle Bar Rock Frame Slide Block
		Screw Stud
2003870	17330	Needle Bar Rock Frame Slide Block
		Screw Stud Set Screw
249270	17329	Needle Bar Thread Guide
2001751	17329	" " Screw
200125F	17329	" Set Screw
207072	15746	Presser Bar Bushing (2)
200352C	15746	" " Set Screw (2)
202671	15746	" " Lifter
200653C		" " Hinge Screw
207963	15746	" Lifting Releasing Lever
		Bracket
200975F	15746	Presser Bar Lifting Releasing Lever
		Bracket Guide Screw
206608	15746	Presser Bar Lifting Releasing Lever
		Bracket Spring
202337	15746	Presser Bar Position Guide
202338	15746	" " " Lever with
		200086F
200086F	15746	Presser Bar Position Guide Lever Pinch
		Screw
200352C		Presser Bar Position Guide Set Screw
207965	17330	" " Spring (flat)
210949	15746	" " Bracket with
20000/6		200086C
200086C	15746	Presser Bar Spring Bracket Pinch Screw
350346C	17330	Presser Bar Spring Regulating Screw
200948F	17330	" " Support Screw
201997	15746	Roller Presser, 1 in. diam., 5/32 in.
		face (fine) with 1528J, 201699C,
		350104C and twenty-eight 206417
249056	15746	Roller Presser Arm
249057	15746	" " 249056 with 201997
233807	15746	" " Bracket
235088	15746	" " " Position
		Collar with 200362C
200117F	15746	Roller Presser Arm Bracket Position Collar Position Screw
200362C	15746	Roller Presser Arm Bracket Position
_		Collar Set Screw
202558	15746	Roller Presser Arm Bracket Spring
202559	15746	" " Stop
200141F	15746	11 11 11 11 11
		Screw
200096D	15746	Roller Presser Arm Screw
249058	15746	Roller Presser and Bar complete, Nos.
		200096D, 200117F, 202557 to 202559,
		THE THE PIPE HILL THE
		200141F
206417	15746	Roller Presser Ball, 1/16 in. diameter
		·

	•	1 O
No.	Plate	Name
2016990		Roller Presser Ball Cone
202557	15746	" " Bar
3501040		" " Hinge Screw
1528J		" " " Nut
237762	17329	Take-up Lever
202399	17329	•
202277	17329	Driving Stud with 202211
202211	17329	Off Facking
202400	17329	(wick)
202423	17329	Take-up Lever Hinge Stud with 202423
202423	11329	Off Facking
200383C	17330	(wick)
202401		Take-up Lever Hinge Stud Set Screw
202401 200132E	15746 15746	Otting Pett
		OCIEW
244048	17314	Tension Disc (back)
244049	17314	(II One)
202404	15746	Kelease I langer
244061	17314	Washer
223438	17314	opr mg
263106	17314	wasner
200625F		Didd with 204725
200061C		Det Berew
204925	17314	Washer
201572X		Indino ital
240358	17314	Tension complete, Nos. 200625F, 201572X
		202410, 223438, 244048, 244049, 244061
2021.0		and 263106
202410	17314	Thread Controller Spring
241443	17314	Stop
200132E	17314	BCIEW
202412	17325	" Guide
210955	17314	" (upper)
200582X	17314	" " Screw (2)
241755	15745	" Lubricator Oil Pad (felt)
237779	15745	" " Holder
240439	15745	" " Retainer
241758	15745	" " Reservoir
241759	15745	" " Wick
350432XC		" Screw
201650X	15745	" Nut
214838	15745	" " Washer
237780	15745	Thread Lubricator complete, Nos.214838
		237779, 240439, 241755, 241758 and
		241759
240034	17314	Thread Retainer
210956	17314	" Bracket with 200397X
200582X	17314	" " Screw (2)
200366X	17314	" Set Screw
210993	17314	" " Sleeve
223144	1730*	. डेट्टर जब्
210957	17314	" " Stud
210958	17314	" " " Collar

No.	Plate	Name
200397X	17314	Thread Retainer Stud Set Screw
210959	17314	Thread Retainer (lower) complete, Nos.
		210956 to 210958, 210993 and 223844
249179	15749	Throat Plate Body
249180	15749	" " Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin, 045
		in.)
200587D	15749	Throat Plate Needle Plate Screw
249181	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249180 and two
		200587D
200099X	15749	Throat Plate Screw (2)
249066	17330	Vertical Shaft
237745	17330	" " Bevel Gear (lower)
205508	17330	" " " " Position
		Pin
235857	17330	Vertical Shaft Bevel Gear (upper) with
		200374C and 200396C
200396C	17330	Vertical Shaft Bevel Gear (upper) Posi-
		tion Screw
200374C	17330	Vertical Shaft Bevel Gear (upper) Set
		Screw
237734	17330	Vertical Shaft Bushing (lower)
200346C	15739	" Set Screw
237746	17330	" " (upper)
200362C	17330	Set Screw
237747	17325	Diving dear with 2003/40
20020/0		and 200396C
200396C	17325	Vertical Shaft Driving Gear Position
200271.6	17225	Screw
200374C 249067	17325	Vertical Shaft Driving Gear Set Screw
•	17330	Oil Leader (lower) (brass)
237755	17325	" " " (upper) (brass)

SINGER Needles should be used in SINGER Machines These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO.**";

FOR SINGER MACHINES
are NOT SINGER made needles.

ACCESSORIES

N1 -	D1 - 4 -	None
No.	Plate	Name
233939	17313	Bobbin (2)
228288	15751	Drip Pan with four $3/4$ in. wire nails
238632	15740	Feed Wheel Driving Pinion Spacing
Ĺ		Washer (for use in place of Feed
•		Wheel Driving Pinion when one or
		two lengths of stitch are required) (2)
238508	17328	Knife
41400	15757	Machine Rest Pin (wood)
16 x 4		Needles, three each, sizes 12 and 13
120342	15757	Oiler (copper plated) with 120343
120343	15757	" Spout (3-1/2 in. long)
4822	15757	Roller Presser Hinge Screw Nut Wrench
225498	15757	Screw Driver (7-1/4 in. long)
228476	15757	" (Bobbin Case)
225554	15757	Wrench (steel)

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)
FOR 5/16 INCH ROUND BELT DRIVE

259428	16615	Brake (leather)
259429	16615	" Clamp
200113F	16615	" Screw
225453	16615	Frame with 202277 and 259660
225454	16615	" Hinge Pin
202277	16615	" Oil Packing (wick)
259660	16615	" Well Washer
225455	16615	" Spring
225456	16615	" " Plunger
225368	16615	Pulley with 200380C
200380C	16615	" Set Screw
225381	16615	Spindle
225444	% 16615	Stop Latch
200056E	16615	" " Screw
225458	16615	" " Thumb Lever
2754251	ी तेली हैं हैं	' Ange His
22545°	15017	किल्ला डिवर्स
202,78	16415	Trip Lever
SHI:SDEX	2 fot] =	ी भी तबूक उ त्तरक्रम
22 5 % I	16615	Tension Bracket with 201400X

		ACCESSORIES
No.	Plate	Name
200082D	16615	Tension Bracket Screw
228026	16615	" " Washer
2102	16615	" Disc
13710	16615	
201499X	16615	" Spring " Stud
201572X	16615	" " Thumb Nut
225462	16615	Indino Nat
223402	10015	Bobbin Winder Tension Bracket com- plete, Nos. 13710, 201572X, 225461 and
		two 2102
259430	16615	Bobbin Winder and Tension Bracket
23,130	10013	Base
259431	16615	Universal Bobbin Winder complete, Nos.
23,131	10013	200056E, 200082D, 200113F, 200299X,
		202478, 225368, 225381, 225444, 225453
		to 225456, 225458, 225462, 228026,
		259428 to 259430, two each 225459 and
		wood screws 3/4 in., No. 12, R. H. B.
		wood screws 3/4 m., No. 12, R. H. B.
		KNEE LIFTER
		With the text
2763	17321	Rock Shaft
7539	17321	" " Hanger with two wood screws
		1 in., No. 10
228364	17321	Rock Shaft Knee Plate with 350231C
228318	17321	" " " Arm
228685	17321	" " " Bracket with
		two 356C
356C	17321	Rock Shaft Knee Plate Arm Bracket Set
		Screw
228686	17321	Rock Shaft Knee Plate Arm Counter
		Balance Spring
356C	17321	Rock Shaft Knee Plate Arm Set Screw
150668	17321	" " " Pad (rubber)
350231C	17321	" " Set Screw
6337	17321	" Lifting Bracket with two
		356C
39811	17321	Rock Shaft Lifting Bracket Extension
		with 39576
356C	17321	Rock Shaft Lifting Bracket Extension Set
		Screw
356C	17321	Rock Shaft Lifting Bracket Set Screw
227676	17321	" " Chain, 18 in. long, with
		202784
39576	17321	Rock Shaft Lifting Chain Hook (lower)
202784	17321	" " " (upper)
2770	17321	" " Stop Dog with 140219C
140219C	17321	" " Set Screw
228687	17321	Knee Lifter Rock Shaft complete, Nos. 2763
		2770,6337,39811,150668,227676,
		228318,228364,228685,228686 and two
		7539

FEED GEARS

No.	Plate	Name
249020	15739	Feed Wheel Driving Gear (for 12
		stitches)
249021	15739	Feed Wheel Driving Gear (for 13
		stitches)
249022	15739	Feed Wheel Driving Gear (for 14
		stitches)
249023	15739	Feed Wheel Driving Gear (for 15
21.0021		stitches)
249024	15739	Feed Wheel Driving Gear (for 16
31.0035	15720	stitches)
249025	15739	Feed Wheel Driving Gear (for 17 stitches)
249026	15739	Feed Wheel Driving Gear (for 18
247020	13/37	stitches)
249027	15739	Feed Wheel Driving Gear (for 19
21,021	,	stitches)
249028	15739	Feed Wheel Driving Gear (for 20
		stitches)
238641	15739	Feed Wheel Driving Gear (for 21
		stitches)
249029	15739	Feed Wheel Driving Gear (for 23
		stitches)
238642	15739	Feed Wheel Driving Gear (for 24
330/05		stitches)
238605	15739	Feed Wheel Driving Gear (for 26
238606	15720	stitches)
238000	15739	Feed Wheel Driving Gear (for 29 stitches)
238607	15739	Feed Wheel Driving Gear (for 32
238007	13737	stitches)
249034	15740	Feed Wheel Driving Pinion (for 12
21,031	13,10	stitches)
249035	15740	Feed Wheel Driving Pinion (for 13
		stitches)
249036	15740	Feed Wheel Driving Pinion (for 14
		stitches)
249037	15740	Feed Wheel Driving Pinion (for 15
		stitches)
249038	15740	Feed Wheel Driving Pinion (for 16
		stitches)
249039	15740	Feed Wheel Driving Pinion (for 17
*11 -		stitches)
249040	15740	Feed Wheel Driving Pinion (for 18
11001		stitches)
249041	15740	Feed Wheel Driving Pinion (for 19
		stitches)

Plate	Name
15740	Feed Wheel Driving Pinion (for 20
	stitches)
15740	Feed Wheel Driving Pinion (for 21
	stitches)
15740	Feed Wheel Driving Pinion (for 23
	stitches)
15740	Feed Wheel Driving Pinion (for 24
	stitches)
15740	Feed Wheel Driving Pinion (for 26
	stitches)
15740	Feed Wheel Driving Pinion (for 29
	stitches)
15740	Feed Wheel Driving Pinion (for 32
	stitches)
	15740 15740 15740

KNIFE HONING DEVICE

259281	17640	Base	with	457AL	and to	wo 899)D
259282	17640	11	25928	31 with	674D	,721D	, 259274 to
		25	9277,	259309	, 2593	10, 35	0372C and
		35	0373				
259266	17640	Knife	Hold	er Clan	np		
259267	17640	*1	11	**	Bas	e	
259268	17640	11	**	11	**	2592	67 with
		77	1X, 13	59J, 36	006,4	1544,	259266,
		25	9269 :	and 259	284		
899D	17640	Knife	Hold	er Clan	пр Ва	se Lo	cking
		Th	umb 8	Screw			
1359J	17640	Knife	Holde	er Clan	np His	ige Sc	rew
36006	17640	**	**	"	,	•	" Washer
259269	17640	*1	11	11	Spr	ing	
259284	17640	11	11	**	Was	her	
771X	17640	11	**	Clamp	ing T	humb	Screw
41544	17640	11	11	***	-	11	11
		₩a	sher				
259270	17640	Knife	Hone				
259271	17640	11	" (Clamp			
215057	17640	11	**	'' P	ositio	n Pin	
200466X	17640	11	11	'' T	humb	Scre	w
259272	17640	**	11	Holder	with	two 2	15057
259273	17640	11	**	" 2	59272	with	259270, two
		eac	h 200	466X a	nd 25	9271	
259274	17640	Knife	Hone	Holder	Guid	e	
259275	17640	11	**	11	*1	Colla	ar
721D	17640	11	11	11	**	**	Set Screw
259276	17640		11	11	11	11	Yoke
674D	17640	**	11	11	11	**	" Hinge
		Scr	ew				

No.	Plate			Name
259277	17640	Knife	Hone	e Holder Guide Collar Yok
		Hi	nge S	Screw Bushing
350372C	17640	Knife	Hone	e Holder Guide Collar Yok
		Hi	nge S	Screw Bushing Set Screw
350373X	17640	Knife	Hone	e Holder Guide Thumb Set
		Sc	rew	
259310	17640	Knife	Stop	Pin (long)
259309	17640	11	**	" (short)
457AL	. 17640	11	11	" Set Screw
899D	17640	11	11	" Thumb Screw
259283	17640	Honin	g Dev	evice complete, Nos. 259268
		259	9273,	, 259282, Form 2399W and
		thr	ee w	vood screws 1-1/2 in., No.

THROAT PLATES

249179	15749	Throat Plate Body
249187	15749	" " Body
249182	15749	" Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin .035 inch)
249180	15749	Throat Plate Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin . 045
		inch)
249188	15749	Throat Plate Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin .045 inch)
200587D	15749	Throat Plate Needle Plate Screw
249181	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249180 and two
		200587D
249183	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249182 and two
		200587D
249189	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249187, 249188 and two
		200587D (for long stitch)


WOOD BASE


(OBLIQUE)


No.	Plate	Name
202259		Bed Hinge Plate
227493	15751	" " 202259 with two wood
		screws 7/8 in., No. 12H
225589	15751	Machine Cushion (leather)
228357	15751	Base with two 227493, four 225589 and
		eight wood screws 1-1/2 in., No.7


SINGER Needles should be used in SINGER Machines
These Needles and their Containers are marked with the
Company's Trade Mark "SIMANCO." 1


Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles.





















201499H







Download from Www.Somanuals.com. All Manuals Search And Download.












Download from Www.Somanuals.com. All Manuals Search And Download.





Download from Www.Somanuals.com. All Manuals Search And Download.





Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com