



Home Generator Systems


Illustrated Parts List

**Model
040275**

**15000 Rated Watts
Home Generator System**

Manual No. 194689A Rev. B (03/28/2008)

Exploded View - Main Unit



Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.


Illustrated Parts List - Main Unit

Item	Part #	Description	Item	Part #	Description
1	AA203030GS	BASE, Mounting	51	NSP	ASSY, Alternator (see page 7)
2	187594GS	MOUNT, Vibration	52	692062	SCREW
3	24910GS	HHS, Trilobular 5/16 - 18 x 1/2	53	193506GS	DECAL, Caution Hot Surface
4	194683GS	SOLENOID, Gas Fuel	54	809872	GASKET
5	194829GS	FITTING, Coupling	55	197164GS	MUFFLER
6	194830GS	REGULATOR	56	194681GS	BASE, Muffler Box
7	195936GS	BRACKET, Mounting Solenoid	57	198928GS	KIT, Insulation, Muffler Base
8	842184	ASSEMBLY, Tee	58	56893GS	CRIMPTITE, 10 - 24 x 1/2
9	*	HHCS, M6 - 1.0 x 16	59	203396GS	ASSY, Bulkhead, Alt End w/Insulation
10	*	HHCS, M6 - 1.0 x 30	60	198929GS	KIT, Insulation, Muffler Box
11	*	WASHER, 1/4 Lock	61	194682GS	COLLECTOR, Muffler Box
12	*	NUT, M6 - 1.0	62	194680GS	BOX, Muffler Top
13	B4300GS	HHS, Trilobular, 1/4 - 20 x 1/2	63	192445GS	SCREW, 10 - 32 x 5/8
14	194818GS	BATTERY	64	*	PPHMS, 4-40 x 0.19
15	185939RGS	WIRE-A, Black	65	*	WASHER, Lock #4
16	198913GS	KIT, Battery Hardware	66	186205GS	SWITCH, Oil Temp
17	198593AGS	WIRE-A, Red	67	194699GS	PLATE, Switch Oil Temp
18	194813GS	TUBE, Air Cleaner	68	186790CGS	WIRE
19	*	HHCS, M6 - 1.0 x 12	70	205397GS	DECAL, Requirements, Fuel
20	*	WASHER, Flat 5/16 - M8	900	§	ENGINE
23	1723165SM	HOSE, Oil Drain	901	843644	FUEL HOSE
24	186649GS	DECAL, Oil Drain	902	843438	CLAMP
25	*	HHCS, 5/16 - 18 x 2.5 Full Thread	Items Not Illustrated		
26	*	NUT, 5/16 - 18	203369GS		MANUAL, Install
27	*	WASHER, Lock 5/16 - M8	203370GS		MANUAL, Operator's
28	*	HHCS, 5/16 - 24 x 3/4 SEMS	MS3483		MANUAL, Engine
29	*	HHCS, 5/16 - 18 x 2"	203393GS		KIT, Manual/Accessory, HGS
30	*	HHCS, M12 - 1.75 x 35	203374GS		PAINT, Touchup, Bottle, Continuum
31	*	WASHER, M12			Charcoal, 1/2oz
32	B194685GS	SUPPORT, Engine/Alternator, Black	198811GS		PAINT, Touchup, Bottle, Metallic
34	*	WASHER, Shakeproof Ext. M6-1/4			Silver, 1/2oz
35	186790FGS	WIRE, Ground	B3518GS		CAP, Funnel Oil Bottle
36	*	WASHER, Lock M10	202295GS		HOSE, Flex
37	*	WASHER, Flat, M10	198866GS		KIT, Led Remote
38	*	HHCS, M10 - 1.5 x 30	203419GS		KIT, Decals, Service
39	B196639GS	BRACKET, Mounting Alternator, Black	Optional Accessories		
40	196387GS	DUCT, Air	203417GS		PAINT, Touchup, Spray, Continuum
41	*	PPHMS, M5 - 0.8 x 20			Charcoal, 12oz
42	*	WASHER, Lock 3/8	199475GS		PAINT, Touchup, Spray, Silver, 12oz
43	*	SHCS, 3/8 - 16 x 1-1/4	6030		KIT, Cold Weather (Includes Battery and Oil Warmers)
44	*	HHCS, 5/16 - 18 x 3/4			
45	*	WASHER, M12 Lock			
46	*	NUT, Hex M12 - 1.75			
47	*	WASHER, Flat M12			
48	*	NUT, M10 - 1.5			
49	B4260GS	DISK, Engine Air			
50	809743	SCREW			

* - Items without part numbers are common fasteners and are available at local hardware stores.

§ - Contact Engine Manufacturer

Exploded View - Enclosure




Illustrated Parts List - Enclosure

Item	Part #	Description	Item	Part #	Description
1	197275GS	PAD, Mounting w/ Holes	16	194819GS	SEAL, Foam, Engine Air
2	AA203030GS	BASE, Mounting	17	203303GS	INSULATION, Engine Door, Bottom
3	203383GS	ASSY, Bulkhead, Engine End	18	195733GS	MOUNT, Tie Wrap
		. Bulkhead, Engine End	19	195935GS	DUCT, Rubber Alternator
		. Decal, Fuel Inlet	20	194820GS	SEAL, Foam, Alternator Inlet
		. Seal, Foam	21	198893GS	ASSY, Roof/Siderails
		. Seal, Foam Engine Air			. Weldment Roof/Siderails
		. Bushing, 1-1/2			. Insulation
		. Bushing, 1-3/8	22	203396GS	ASSY, Bulkhead, Alternator End
		. Plug, Dome 1-1/2			. Decal, Caution Hot Muffler
		. Pin, Hinges with Hardware			. Seal, Foam
4	203380GS	ASSY, Door, Engine. End			. Seal, Foam Alternator Inlet
		. Weldment, Door Engine End			. Pin, Hinges with Hardware
		. Insulation			. Bracket, Muffler
		. Barrel, Hinges with Hardware	23	200409GS	DECAL, Caution Hot Muffler
5	198910GS	ASSY, Duct, Engine Air	24	194679GS	COVER, Air Intake Alternator
		. Decals	25	198926GS	ASSY, Vent, Exhaust
		. Lug, Ground Connect w/Hardware	26	B1797GS	CLIP, Tree
		. Bracket, Mounting Breaker	27	198927GS	ASSY., Vent, Alternator
		. w/Hardware	28	198888GS	SEAL, Foam
6	203385GS	ASSY, Support, Rail	29	194694GS	COVER, Air Intake Engine
		. Support Rail Engine. End	30	203302GS	INSULATION, Engine Door, Top
		. Seal, Foam	31	197312GS	SEAL, Foam
		. Decal, Rainproof	32	196397GS	INSULATION, Front/Rear Door
7	B4300GS	HHS, Trilobular, 1/4-20 x 1/2	33	195597GS	INSULATION, Roof
8	186173GS	BUSHING, Snap, 1-3/8"	35	198460GS	PLUG, Dome
9	197493GS	BUSHING, Snap, 1-1/2"	36	192940GS	RETAINER, Hose
10	198461GS	PLUG, Dome, 1-1/2"	38	198890GS	KIT, Door, Hinge
11	*	HHCS, 3/8 - 16 x 1	39	194828GS	SET, Latch Key
12	*	WASHER, Flat, 3/8 - M10	40	198889GS	KIT, Door Latch
13	*	WASHER, Lock 3/8			
14	*	NUT, 3/8 - 16			
15	203381GS	ASSY, Door			
		. Weldment Door			
		. Insulation			
		. Barrel Hinges with Hardware			
		. Decals			

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Illustrated Parts List - Control Panel



Item	Part #	Description
1	198911GS	ASSY, Cover, Circuit Breaker w/ Decals
2	*	SCREW, 10 x 0.62, Plastite
3	198313GS	BREAKER, Circuit 70A, 2P
4	192770GS	BRACKET, Mounting Breaker
5	199011GS	LUG, Ground Connect
6	191991GS	BOLT, 1/4-10 x 1, Plastite
7	198573GS	FUSE, Auto Type 15 Amp
8	202118GS	ASSY, Control Panel
9	197492GS	SCREW, PT, M4 - 1.79 x 16.0
10	198910GS	ASSY, Duct, Engine Air w/ Decals
12	198549GS	DECAL, Terminal Block
13	198550GS	DECAL, Ground, Neutral
14	205393GS	DECAL, Warning, Outdoor Install
15	193297GS	DECAL, Caution, Standby
16	205392GS	DECAL, Warning, Auto Start


Item	Part #	Description
17	205394GS	DECAL, Caution, Electric Shock
18	205395GS	DECAL, Warning Shock
19	*	NUT, 1/4 - 20
21	*	WASHER, Shakeproof, Ext M6 1/4
22	*	HHCS, 1/4 - 20 x 3/4

Items Not Illustrated

194825GS	HARNESS, Wire, CTL Board to Engine/Alternator
198517GS	HARNESS, Wire, E1 & E2 Sensing
198515GS	CONNECTOR, Terminal, 2 Pin
198516GS	CONNECTOR, Terminal, 10 Pin

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Illustrated Parts List - Alternator



Item	Part #	Description
1	199339GS	BOX, Terminal Lid
2	199340GS	END BRACKET, Non-drive
3	199351GS	FRAME, w/Stator
4	199349GS	BRACKET, Drive End
5	199338GS	CAP, Rubber
6	*	HHCS, M5 x 10mm
7	199341GS	SECURING STUD, Rotor
8	199342GS	BEARING, Rear
9	199343GS	ASSY, Rotor
10	199344GS	RING, Fixing
11	199345GS	FAN
12	199350GS	SCREEN, Protection
13	*	PPHMS, M5 - 0.8 x 20
14	199348GS	STAY BOLT, Cover
15	199347GS	CAPACITOR, 35
16	199346GS	TERMINAL BOARD
17	199352GS	NUT
18	199353GS	WASHER, Flat
19	206145GS	CAPACITOR, 31.5

* - Items without part numbers are common fasteners and are available at local hardware stores.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>