

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



Electronic Digital Safe



Batteries sold separately.

To ensure security of your safe, Bunker Hill Security does NOT provide replacement keys.

Visit our website at: <http://www.harborfreight.com>
Email our technical support at: tech@harborfreight.com

REV 13j

ITEM 45891

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible.

Copyright© 2001 by Harbor Freight Tools®. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

**Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.**

Specifications

Overall Dimensions	9-7/8" H x 11" D (w/Front Panel), 10-1/2" D (w/o Front Panel) x 13-3/4" W
Internal Dimensions	13-1/2" W x 9-1/2" H x 9-5/8" D
Included Items	4 Concrete Fasteners, Felt pad, Hole Template
Power Required	"AA" Batteries x 4
Weight	35.6 lb.

Important Safety Information

1. Verify that installation surface has no hidden utility lines before drilling or driving screws.
2. Wear ANSI-approved safety goggles during installation.
3. Install only according to these instructions. Improper installation can create hazards.
4. Keep installation area clean and well lit.
5. Keep bystanders out of the area during installation.
6. Do not install when tired or when under the influence of alcohol, drugs or medication.
7. Place the Safe on correct surface. Only use this Safe on a stable, level, clean and dry surface that is capable of sustaining the load.
8. **Keep closed and locked whenever unattended. RISK OF CHILD ENTRAPMENT AND SUFFOCATION. Check inside before closing. Do not allow children to play with or near safe. Keep keys and codes away from children.**
9. Keep clear of door when closing.
10. Position batteries in proper polarity and do not install batteries of different types, charge levels, or capacities together.
11. Use as intended only.
12. Inspect before every use; do not use if parts are loose or damaged.
13. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
14. Do not store Keys inside of the Safe. **Place your emergency keys in a location outside of the safe making sure they are in a secure location that you can find.**
15. Warning: The brass components of this product contain lead, a chemical known to the State of California to cause birth defects (or other reproductive harm). (California Health & Safety code § 25249.5, et seq.)
16. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
17. The Safe is not fireproof.

NOTE: Harbor Freight Tools is not responsible for the loss of any property stored within this safe due to theft, fire, or any other circumstance.

Installation

1. The safe has four concrete fasteners that are inside of the safe when you open it. There is also a mounting template included with the safe. Place the mounting template against the area you will be mounting the safe and tape it into place.
2. To attach the safe to a wood surface, hammer a nail (not included) to mark the hole placement. Drill an 1/8" diameter pilot hole into each mounting hole location. Place the safe over the mounting holes and secure the safe using four 1/4" diameter self-tapping screws (not included).
3. To use the concrete fasteners, drill a small pilot hole through the template to mark the hole placement. Next drill four holes in the correct location, using a concrete drill bit. Drill the holes the same diameter as the fasteners and 2" deep. Hammer the fastener in the hole with the flat side going into the hole first. Use a wood block between the bolt and the hammer to protect the threads.
4. Place the safe over the bolts (with the nut removed from the bolts) and tighten a nut onto each bolt. As you tighten the nuts onto the bolts, the fasteners will expand inside the cement, securing the safe into place.

WARNING! Before drilling or driving nails, make sure there are no wires, cables or pipes in the path.

Operation

1. To Open the Safe: Input the numbers "159" on the Electronic Key Pad, then press either the "A" or "B" Key. Once the Green light is on, turn the Knob and pull the Door open. Note: The knob must be turned within 5 seconds of the Green light coming on. If the knob is not turned, the entry code will need to be re-entered.
2. To Close: Close the Door and turn the Knob in the opposite direction. The Safe is now locked.
3. To Change the Code: The Safe comes preset with a default code of "159." To change the Code, first follow the instructions for opening the Safe. On the inside of the Door toward the hinge, you will see a small Red Button. Press this Button until the Yellow Light on the Front Control Panel lights up. Now you can input the new Code (1 to 8 characters) into the Front Control Panel, followed by either the "A" or "B" Key. The Safe will beep twice to confirm that the Code has been changed. Important: If the Safe beeps three times, then the Code has not been accepted, and you must repeat the steps above.
4. To Change the Batteries: If the Red Light and the Green Light are both lit at the same time, it is time to change the Batteries. Follow the instructions for opening the Safe. The Battery Compartment is located on the inside of the Door. Slide the Battery Cover off of the Battery Compartment, remove used Batteries, and insert four new "AA" Batteries. Once you have changed the Batteries, be sure to test the Code before you close the Door again.

5. Using the Emergency Key:
 - a. Peel off the Label directly to the left of the keypad to reveal the Secret Key-Operated Lock.
 - b. Insert Emergency Key into the Secret Key-Operated Lock.
 - c. Turn Knob and pull Door open.
 - d. Replace the Keypad and the Label when finished.

IMPORTANT: NEVER LOCK THE EMERGENCY KEYS IN THE SAFE!

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Record Serial Number Here: _____

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item.



3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • (800) 444-3353

REV 04a, 07b

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>