

CamPocket Flash camera bags

A practical camera bag for digital equipment

The CamPocket Flash is equipped with a thick cushioned compartment to safely transport and store digital equipment. The front flap of the Focus is secured with a velcro fastening keeping the camera safe but at the same time allowing for fast retrieval when needed. The two side flaps of the main compartment additionally protect the contents from above and prevent water and dirt from entering the bag and possibly damaging the equipment.

The CamPocket Flash offers lots of room in the attached front compartment for batteries, whilst the two integrated pockets can carry your memory cards.

The CamPocket Flash can be carried in the hand, on the removable shoulder strap, or by using the button-activated belt loop.

Flash is made of high-quality, robust, artificial leather, available in black.



Specification:

Colour:	Black
Dimensions:	110mm x 80mm x 60mm OR 4.3" x 3.2" x 2.4"
For Cameras Up To:	95mm x 70mm x 40mm OR 3.7" x 2.8" x 1.6"
Weight:	90g
Material:	Koskin

Part Codes:

D7988KHY	CamPocket Flash
----------	-----------------



Available from:

Hypertec Ltd

2 Swangate, Charnham Park, Hungerford, Berks, RG17 0YX

t: 0870 243 5603 f: 0870 243 5604

w: www.hypertec.co.uk

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>