Recommended Xerox Media for Phaser 6125N, 6128MFP, 6130N, 6140N, 6500 & WorkCentre 6505DN

(Europe)
Version 1.0, Publish Date: February 2011

Important Note:
All media are listed by product, Paper Type System Setting, Paper Type, weight (standard gsm), re-order number, size, and tray runability. The additional information column is for hints and tips on how to run certain media applications.

Media recommendations made in this publication are based on qualification tests* conducted using standard test images with moderate to heavy image area coverage.   Test duration for each product/media type is based on the suggested machine monthly copy/print volume. Test machines are maintained within specifications defined by user documentation.

*Testing environment Temperature 20 degreesC±4, Relative Humidity 40% ±10%.

*Machine reliability specifications may be affected by increased usage of the Transparency, Card Stock, Label, and Special modes. In addition, variances in machine reliability may occur due to extended use of some media types. Your Xerox service representative can advise you on special application media types for long duration copy/print runs.

For specifications and a description of the various media types discussed in this publication, please refer to www.Xerox.com.

**For additional recommended Phaser media, look under Supplies on: http://www.office.xerox.com/ and select your Product Family.**

XEROX®, the sphere of connectivity, and all Xerox product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.

Xerox Europe Recommended Media List

Plain Paper	Glossy Paper
Thin Card	Thick Glossy Paper
Thick Card	
Label	Transparency

February 2011
6125N / 6128MFP
6130N / 6140N
6500 / WC 6505DN

M=Manual Duplex
S=Simplex Only
A*=Auto Duplex
(6140 ONLY)

Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Manual Feed Slot	Tray	Additional Information
Xerox Digital Colour Colotech+ (Gold Label)	Plain	90 gsm	003R98837			A4	M / A*	M / A*	Paper Type *Plain Paper* should be selected on the user interface for Trays or Printer Driver. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
	Plain	100 gsm	003R98842			A4	M / A*	M / A*	
	Plain	120 gsm	003R98847			A4	M	M	
	Thin Card	160 gsm	003R98852			A4	M	M	Paper Type *Thin Card Stock* should be selected on the user interface for Trays or Printer Driver. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
	Thick Card	200 gsm	003R97967			A4	M	M	Paper Type *Thick Card Stock* should be selected on the user interface Trays or Printer Driver. Environmental condition may require that this product be fed one sheet at a time. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
	Thick Card	220 gsm	003R97971			A4	M	M	
Xerox Colour Impressions	Plain	90 gsm	003R97663			A4	M / A*	M / A*	
Xerox Business	Plain	80 gsm	003R91820			A4	M / A*	M / A*	Paper Type *Plain Paper* should be selected on the user interface for Trays or Printer Driver. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
			003R91823		4 HD	A4	M / A*	M / A*	
Xerox Premier	Plain	80 gsm	003R91720			A4	M / A*	M / A*	
Xerox Performer	Plain	80 gsm	003R90649			A4	M / A*	M / A*	
Xerox Recycled	Plain	80 gsm	003R91165			A4	M / A*	M / A*	
			003R91857		4 HD	A4	M / A*	M / A*	

Plain Paper	▭	Glossy Paper	▭
Thin Card	▭	Thick Glossy Paper	
Thick Card	▭		▭
Label	▭	Transparency	▭

February 2011
6125N / 6128MFP
6130N / 6140N
6500 / WC 6505DN

M=Manual Duplex
S=Simplex Only
A*=Auto Duplex
(6140 ONLY)

Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Manual Feed Slot	Tray	Additional Information
Xerox Digital Colour Colotech+ Gloss	Glossy Coated	140gsm	3R97577			A4	M	M	Paper Type *Glossy Paper* should be selected on the user interfaceTrays or Printer Driver. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
	Thick Glossy	210gsm	3R97583			A4	M	M	Paper Type *Thick Glossy Paper* should be selected on the user interface for Trays or Printer Driver. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage. Increasing media weight (gsm) can give increasing levels of curl in the imaged product.
Xerox Premium Business Cards	Thick Card	195gsm	3R97512			A4	M	M	
Xerox Color Laser & Copier Labels	Label		003R93872		1 up	A4	S	S	Paper Type *Labels* should be selected on the user interface for Trays or Printer Driver.
			003R93873		6 up	A4	S	S	
			003R93874		8 up	A4	S	S	
			003R93875		14 up	A4	S	S	

xerox

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com