



BlueCore5™

BlueTunes2 Stereo Headset Quick Start Guide

Additional Information

Using the Analogue-Audio Adaptor board

The Analogue Audio Adaptor solution from CSR makes it easy to design and manufacture Bluetooth adaptor products for mobile handsets, MP3 players and Hi-Fi systems. This allows products without built-in Bluetooth to connect to wireless headphones and speakers.

Connecting to wireless speakers or headphones

Screw the supplied helicoil antenna clockwise onto the base. The first time the audio adaptor is turned on it will automatically start searching for Bluetooth headphones, speakers or other A2DP sinks in range. When it finds one, it will try to pair with the device using a fixed PIN code stored in Flash memory (as shipped, the PIN code is 8888). If the pairing process is successful, it will set up an A2DP connection and start streaming music.

Pressing the button on the development board will delete any pairing information and start the adaptor looking for further suitable A2DP sources. Make sure the A2DP sink device is in pairing mode, otherwise it will not be visible.

LED patterns

The LED flashing indicates the state of the audio adaptor board:

- **Idle:** the blue LED flashes; 100ms on, 1000ms off.
- **Discovering:** both red and blue LEDs flash.
- **Streaming:** the blue LED flashes; 1000ms on, 1000ms off.

Using the Voice Dongle

The Voice Dongle 1 is a true plug-and-play dongle that allows a Bluetooth headset to be used for VOIP (Voice-Over-IP) calls.

Connecting the Voice Dongle to your headphones

1. Insert the dongle into a USB socket on your PC.
2. Ensure that the headset is in pairing mode, as described on page 2 of this document.
3. Press and hold the button (clear plastic window) on the dongle until the LEDs flash with a red-green-pause sequence (as oppose to *red-green-red-green*). This flashing sequence indicates that the dongle is in pairing mode; the dongle should now pair with your headset.

Pressing and releasing the button on the dongle causes the dongle to attempt pairing with the last-paired device. In this state, the LEDs on the dongle flash in a *red-green-red-green* sequence.

CSR plc

Cambridge Science Park Milton Road Cambridge CB4 0WH Tel: +44 (0)1223 692000 Fax: +44 (0)1223 692001



BlueCore5™

BlueTunes2 Stereo Headset Quick Start Guide

This Quick Start Guide is designed to help you set up your BlueTunes2 Stereo Headset Evaluation Kit. For more information please visit the BlueTunes2 section at www.csrsupport.com ⁽¹⁾

Please check and identify the following components. Email sales@csr.com if any components are missing. You will need these components to set up your BlueTunes2 Stereo Headset Development Kit. ^(2,3)



1 BC5MM-EXT Headset Example Design Demonstrator Board including 1 Lithium/Ion Polymer Battery (120mAH)



1 Pair of Stereo Headphones



1 CSR Nanosira Multimedia Dongle




1 Mini-B USB cable



Notes:


- (1) The evaluation kit is supplied with development firmware which is not suitable for production. Qualified firmware is expected in early 2007 and will be available for download from www.csrsupport.com on release.
- (2) The following additional components are also supplied: 2 Host-interface boards, 1 USB AV-dongle, 1 USB Voice Dongle, 1 Analogue audio-adaptor board, 1 serial UART cable, 1 SPI cable, 1 XSPI adaptor, 1 stereo jack cable and 1 helicoil antenna. These components will help with more advanced evaluation and testing (such as described briefly on page 4)
- (3) CVC software requires a security key for continued operation. If the audio mutes after 5 minutes, please contact your CSR sales channel to obtain a valid CVC security key.

Step 1: Setting Up the Demonstrator board



1. Choose between the on-board antenna ("ANT") or the SMA RF connector ("CON") using this slide switch. Set to "ANT" for normal operation.
2. Connect the Lithium/Ion polymer battery here.
3. Set this switch to "MIC" to use the microphone on the supplied headphones.
3. Set this switch to "AMP"
4. CSR recommends charging the battery for two hours prior to first use. To charge, connect USB cable to USB/Charge port on PCB and USB port on PC. Ensure that the power switch is in the "ON" position.
5. Insert headphone speaker jack here.
6. Insert headphone MIC jack here.

Step 2: Preparing the Demonstrator Board for Bluetooth Pairing



1. Turn the power on.
2. Press the PWR button for five seconds.
3. Red and blue LEDs flash quickly together. The device is ready for Bluetooth pairing.

Step 3: Streaming Music from the PC

Note: Before commencing, CSR recommend downloading the program `avcontrol.exe` from www.csrsupport.com/BlueTunes. This program allows fine control over the behaviour of the Nanosira dongle and allows the user easily to determine the state of the device.



1. Before inserting the Nanosira dongle into the PC, ensure that the demonstrator board is in Bluetooth pairing mode (see Step 2: *Preparing the Demonstrator Board for Bluetooth Pairing*). This reduces the possibility of the dongle pairing with any other Bluetooth device in pairing mode.⁽¹⁾
2. Insert the Nanosira dongle into a USB port on the PC. On first insertion the PC will display a message confirming that it has found new hardware.⁽²⁾
3. The dongle automatically pairs with the demonstrator board.
4. Open a media player on the PC (eg., Windows Media Player) and play an audio/music track. The audio/music track is streamed to the stereo headphones.
5. Use the volume buttons (VOL- and VOL+) on the demonstrator board to control the volume. (The device will beep when the maximum/minimum volume is reached)
6. Use the BACK button to rewind/go back a track. Use the FWD button to fast forward/go forward a track. Use the PLAY/STOP button to stop, pause and play tracks.

Notes:

- (1) If the dongle pairs with the wrong device, start the `avcontrol` program. Select **Discover New Headphones**; the stored Bluetooth address clears and the pairing process begins again.
- (2) If required in the future, the dongle can be uninstalled from the PC in the following way: go to Control Panel and run the Add/Remove Hardware Wizard. Remove USB Audio Device from the hardware list.

Step 4: Receiving a Mobile Phone Call



1. Ensure the demonstrator board is in pairing mode (see Step 2: *Preparing the Demonstrator Board for Bluetooth Pairing*).⁽¹⁾
2. Go to the Bluetooth connectivity settings on the mobile phone. Ensure the phone's Bluetooth capability is on.
3. Search for the BlueTunes2 device. Select/pair with the BlueTunes2 device. Enter the passcode/PIN 8888.⁽¹⁾
4. When a telephone call is made to the mobile phone, any music/audio streaming to the headset from the PC is paused, and the phone call received in the headset. When the phone call is completed/rejected, any music/audio streaming is resumed.

Note:

- (1) If the mobile phone pairs with the wrong Bluetooth device, clear/edit the phone's list of paired Bluetooth devices, and search again.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>